

INSTALLATION INSTRUCTIONS

WALLCOVERING: CAPRIO

Thank you for your purchase. Below are the hanging instructions, intended to help you achieve a beautiful installation. Before proceeding with your installation, check your material and paperwork to ensure you have received the correct product / colour and quantity. Check for signs of defects prior to installation. If you have any questions, please contact your nearest Instyle office.

Please note that Instyle is unable to entertain product claims if more than three drops of material is cut or glued.

Recommended Primer: Pigmented Acrylic Wallcovering Specific Primer

Recommended Adhesive: Non-strippable, heavy duty, clear wallcovering adhesive.

Recommended Wall Surface: Level 4 plasterboard finish or similar.

Seams / Paneling Visibility: Seamless with no paneling

Hanging Directionality: Straight.

Pattern Matching: Non-match

Trimming / Hanging Method: Pre-trimmed, butted on wall. At installers discretion, should additional trimming be necessary, we recommend table-trimming.

Recommended Smoother / Roller: Soft Bristle Brush and Soft Roller

Wrapping Corners: Wood veneer does not crease without the risk of splintering; therefore, we advise against wrapping corners with this product.

1. Do not attempt to cut or install this material until you have read these instructions in full. Begin by inspecting material to ensure it is visually defect free and matches the paperwork.
2. Using correct wallcovering primer, apply primer to wall and allow to dry.
 - a. Make sure location is properly climate controlled.
3. Apply paste to backing of material using an adhesive roller. Avoid oversoaking and ensure even application. DO NOT USE a pasting machine as it will add too much water content to paste.
4. Once material has been properly booked to ensure proper level of tack, apply material to the primed wall.
 - a. Hang material in sequence as it comes off the roll, including short drops around windows, doors, and other obstructions on your wall.
5. DO NOT get adhesive on the face of material. Adhesive is very difficult to clean and removal after it is dry is likely to result in damage to wallcovering face. Dried adhesive tends to leave a hazy appearance.
 - a. To avoid getting adhesive on the face of material, we recommend using a low-adhesive safe-release painters' tape on the seams to keep the product face clean.
6. When trimming this product, we advise you to use a new razor blade with each cut. A dull razor blade is the primary cause of fraying and unsightly seams. DO NOT USE a seam buster.

Pattern Notes: Wood veneer can occasionally curl. We advise that you lay material flat prior to installing to prevent curling during installation.

CARE + MAINTENANCE INSTRUCTIONS

General maintenance can be achieved with periodic dusting and / or vacuuming of materials using a soft bristle brush. Marks and stains can be cleaned using mild soap and water. Avoid all solvent based cleaners and use a blotting technique with a soft sponge. Abrasives and scrubbing can destroy the material face if used. Dry the cleaned area with a lint-free towel. Always test your cleaning method on a sample or inconspicuous part of the installation prior to cleaning the affected area to ensure no damage will occur.