

IMPORTANT

Please ensure the correct care instructions are followed:

Screen: For screen fabrics on workstations, partitions and wall panels

Soft Furnishing: For polyester soft furnishing fabrics on bedspreads, privacy screens or curtains

Healthcare: If thermal disinfection for healthcare is required, please refer to Instyle Healthcare Polyester Care Instructions

SCREEN CARE INSTRUCTIONS

Product Type: textile fabric, non-pile

Textile Type: non-removable screen / partition fabric

Warning

- Below are the appropriate care instructions for screen fabrics
- Care must be taken when cleaning upholstered screens and panels as these instructions apply to the fabric only and the possible effect of the cleaning regime on underlying foam, glue or backing board must be considered.
- For these reasons it is strongly suggested spot cleaning only is used and that it be carried out by a professional cleaner
- Important: if using a polyester screen fabric for soft furnishings such as bedspreads, privacy screens or curtains please refer to Instyle Polyester Soft Furnishings Care Instructions. If thermal disinfection in a healthcare situation is required, please refer to Instyle Healthcare Polyester Care Instructions

Regular Care

- Protect from direct sunlight

Cleaning

- Refer to Warning above
- Professional cleaning recommended
- Treat spills and stains as soon as possible
- Gently wipe any soil or liquid from the surface of the fabric with a clean soft cloth
- May be cleaned with a hot water extraction machine using upholstery detergent only. Apply strictly according to manufacturers instructions
- Test any cleaning products on an inconspicuous area prior to commencing cleaning
- Do not scrub or use brush of any type
- Do not use dry cleaning solvent, dishwashing or laundry detergents
- Do not saturate fabric and importantly do not wet foam or backing board
- Dry away from direct heat and sunlight

LAUNDRY GUIDELINES FOR POLYESTER HEALTHCARE FABRICS

Our polyester healthcare fabrics are easy to wash, dry quickly and have minimum shrinkage.

The following recommendations have been prepared to assist in the care of your polyester healthcare fabric.

Laundry Sorting

- Do not wash with cotton articles
- Colours and whites should be washed separately
- Wash heavily soiled articles separately

Washing

- Use a reduced load (approx. half) of usual
- Break wash 59-68°F (15-20°C) for 3 minutes with detergent (do not wash with soap)
- Main wash 167-176°F (75-80°C) for 12 minutes with detergent as above
- A chlorine based disinfectant may be used

Rinsing

- Rinse thoroughly
- Avoid crash cooling which will cause excessive and permanent creasing
- Rinse a second time with cold water
- Do not use softener or fabric conditioner unless it has been tested for its effect on flammability of fabrics

Drying

- Short tumble dry – max 176°F (80°C)
- Do not over dry as this causes static
- For calendaring ensure articles have a residual moisture of 20 – 30%
- Keep dry wash below 248°F (120°C) on calender

Note these instructions are not appropriate for Instyle product ICE.

LAUNDRY GUIDELINES FOR POLYESTER SOFT FURNISHING FABRICS

- Warm machine wash. Please note that wash temperature for ICE is not to exceed 40°C
- May be tumble dried warm
- Warm iron
- Drycleanable (P)