



ONLINE

—

A sophisticated fine line
stripe textile with a subtle
colour palette

INSTYLE



COMPOSITION	100% polyester
WIDTH	220cm (width becomes length when railroaded)
WEIGHT	212gsm
PATTERN REPEAT	H 29cm V nil (railroaded)
ROLL SIZE	50m approx.
CARE CODE	Curtain/Bedsread: Polyester Healthcare Partition/Wall Panel: Screen Care Soft Furnishing: Polyester Soft Furnishings
LIGHTFASTNESS AS 2001.4.21	6+
FIRE RATINGS AS/NZS 1530.3	Ignitability 0 Spread of Flame 0 Heat Evolved 0 Smoke Developed 0-1
AS/NZS 3837	BCA Group 1 Av. Specific Extinction Area 449.5 m2/kg
APPLICATION	curtains, privacy screens, bedspreads, screens, partitions, wall panels Note: protect curtains with suitable lining if exposed to direct sunlight
ORIGIN	Made in Australia

PERFORMANCE

- Reversible design
- Easy to wash, quick drying with minimal shrinkage
- Designed to withstand hospital and healthcare laundry and performance standards:
- AS/NZS 4146 Australian and New Zealand Standard for Laundry Practice
- AS3789.9 Textiles for healthcare facilities and institutions: Curtains and patient bedscreens: fabric performance properties for colourfastness
- AS2663.1 Textiles - fabrics for window furnishings: Uncoated fabrics - dimensional change

ENVIRONMENT + GREEN STAR

- Oeko Tex certified polyester yarn
- Reduced water and energy consumption, recycling of waste
- ONLINE can be used on white vertical surfaces certified by Ecospecfier, AFRDI, ECNZ and GECA
- The Green Star Rating Tool states “Where at least 90% of an item’s mass is certified to a GBCA recognised standard, the item can be entered as a certified product at Level A, B or C.” Therefore any fabric can be used as fabrics are almost always under 10% by weight of a furniture item

LAUNDRY GUIDELINES FOR THERMAL DISINFECTION

Laundry Sorting

- Wash separately. Do not wash with cotton articles
- Colours, whites and heavily soiled articles should be washed separately

Washing

- Use a reduced load (approx 1/2 of usual)
- Break wash 59-68°F (15-20°C) for 3 minutes with detergent (Do not wash with soap)
- Main wash 167-176°F (75-80°C) for 12 minutes with detergent as above
- A chlorine based disinfectant may be used

Rinsing

- Rinse thoroughly
- Avoid crash cooling which causes excessive and permanent creasing
- Rinse a second time with cold water
- Do not use softener or fabric conditioner without prior testing its effect on polyester fabrics

Drying

- Short tumble dry - Max 176°F (80°C)
- Do not overdry as this causes static
- For calendaring ensure articles have a residual moisture of 20 – 30%
- Keep dry wash below 248°F (120°C) on calender

Note: Please contact your account manager for Screen Care Instructions or Polyester Soft Furnishing Care Instructions